

Steam Control Plus

ATTENTION

Observe the operating instructions.

This document is a supplement to the operating instructions. Please observe the operating instructions and the safety notes in particular.

Steam Control Plus enables you to froth milk automatically and create your own individual types of milk foam. This function can also be used to heat up milk or other liquids.

1 Products with Steam Control Plus

Steam Control Plus is a device variant that requires special equipment. Customer Service can set up the product buttons for Steam Control Plus according to your specifications and hand the machine over ready-for-use.

To ensure milk foam of the best possible quality, use ultra-heat treated (UHT) milk cooled to a temperature of 3 °C (± 2 °C).

1.1 Dispensing Steam Control Plus

CAUTION

Risk of burns due to hot steam wand!

Contact with the steam wand and steam can result in burns.

- During operation, touch the steam wand on the handle only.
- Do not touch the steam wand with bare hands when cleaning.

Note

A maximum of 0.5 liters of milk can be frothed.

The frothed milk is hot. For preparation, use a cup with a handle and only touch the cup using the handle.

The steam wand must be cleaned as described here each time Steam Control Plus is used (blow out and damp cloth).



Fig. 1: Dispensing Steam Control Plus

1. Place the cup containing milk (3) underneath the steam wand (2) on the drip tray (4) so that the steam nozzle is fully submerged in the milk.
 - Touch the steam wand on the handle (1) only.
2. Press the button on the display for dispensing Steam Control Plus.



Fig. 2: Dispensing Steam Control Plus

The preparation process starts and the current temperature of the milk is shown in the display (1).

3. Remove the cup from underneath the steam wand as soon as the preparation process is complete.

The request "Blow out steam lance" is shown on the display.



000182

Fig. 3: Blowing out the steam wand

4. Position the steam wand over the drip tray.
5. Confirm the request with "Start" to blow out the steam line.
6. Clean the steam wand from the outside immediately with a clean and damp cloth to remove milk residues.

✓ The dispensing of Steam Control Plus is complete.

If you want to use Steam Control Plus again right after product dispensing, you can interrupt the blow out process of the steam wand by pressing "Close".